



1200 PRO STUDENT DESK

Parts List (11 parts)

1. Side Left	x 1	7. Drawer Front	x 1
2. Side Right	x 1	8. Drawer Side	x 2
3. Top Panel	x 1	9. Drawer Rear	x 1
4. Box Side	x 1	10. Drawer Bottom 3mm	x 1
5. Box Bottom	x 1		
6. Cleat (front of unit)	x 1		

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver.

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 8	
B	Allen Key	x 1	
C	Cams	x 9	
D	Cam Pins	x 9	
E	Set of Drawer Runner 350mm with Runner screw	x 1 x 6	
F	Slimline Handle	x 1	
G	Cable Outlet	x 1	
H	Glides <small>Attached to parts no action needed</small>	x 4	





me&co
QUALITY, AFFORDABLE FURNITURE



1200 PRO STUDENT DESK



Main Assembly

- ▶ Place Top Panel (3) upside down on a soft surface (blanket, etc.) Screw 7 x Cam Pins (D) into 7 small holes using a Phillips screwdriver.
- ▶ Prepare the Cleat (6) and Side Panels (1 & 2) by inserting the Cams (C) in the large holes. Make sure arrow on cam faces the nearest side.
- ▶ Fit the Cleat (6) between Side Panels (1 & 2) ensuring the dowels fit into the holes, secure it using Confirmat screws (A).
- ▶ Attach the Prepared Cleat and Side Panels on the Top panel and tighten using the Cam Pins (D)
- ▶ Attach drawer Runners (E) to Right Side Panel (2) and Box Side (4)

Next →



Drawer Assembly

- ▶ Lay the Drawer Front (7) upside down on a soft surface (e.g., blanket). Screw 2 x Cam Pins (D) into 2 x small holes.
- ▶ Insert Cams (C) into Drawer Sides (8) and place sides into drawer Front (7) and ensure dowels fit into holes and tighten the Cams. Slide Drawer Bottom (10) into grooves.
- ▶ Insert Drawer Rear (9) into sides ensuring dowels fit into holes and secure with Confirmat Screws (A).
- ▶ Fit Handle (F) onto drawer Front (7) with supplied screws.
- ▶ Slide the Drawer into the main body at a downward angle, ensuring the wheels run inside the guides on the sides of the body. Finally Fit the Cable Outlet (G) onto Top Panel (3)



To build the "Drawer Box "

- ▶ Insert Cams (C) into Box Side (4) and attach over the Cam Pin and tighten securely.
- ▶ Slide the Box Bottom (5) into the Sides (2 & 4) and ensure the dowels fit into the holes and tighten with Confirmat Screws (A).

Next ←

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.