






## 900 STUDENT DESK

### Parts List (6 Parts)

1. Side Left	x1	4. Box Side	x1
2. Side Right	x1	5. Box Bottom	x1
3. Top Panel	x1	6. Cleat (front of unit)	x1

### Hardware

<b>A</b>	Confirmat Screws (use the supplied Allen Key)	x 5	
<b>B</b>	Cams	x 8	
<b>C</b>	Cam Pins (using a Phillips Screwdriver (⊕) - not supplied)	x 8	



### Main Assembly

(Please Note: Steps 1-4 must be completed first.)

#### 1. Top Panel Setup:

- ▶ Lay the Top Panel (3) upside-down on a soft surface (e.g., blanket).
- ▶ Using a Phillips Screwdriver (⊕)\*, screw Cam Pins (C) into the 6 small holes on the backside of the Top.

\*Not Supplied

#### 2. Sides Preparation:

- ▶ Insert Cams (B) into the large holes on the Sides as marked in the photo (1 & 2). Ensure the arrow on the Cam (B) faces the nearest SIDE.

#### 3. Attaching Sides to Top Panel:

- ▶ Position the Sides (1 & 2) over the Cam Pins (C) on the Top Panel.
- ▶ Tighten the Cams (B) securely.

#### 4. Cleat Installation:

- ▶ Fit the Cleat (6) between the Sides (1 & 2), ensuring the dowels fit into the holes.
- ▶ Tighten securely using Confirmat screws from the outside.



### Box Assembly

(USE PARTS 4 & 5)

#### 1. Box Side Attachment:

- ▶ Insert Cams into Box Side (4). Attach over the Cam Pins located under the Top (3) and tighten securely.

#### 2. Box Bottom Attachment:

- ▶ Insert Cam Pins into Side (2). Next, insert Cams into the Box bottom (5).
- ▶ Attach the Box bottom over the Cam pins in Side 2 and tighten securely.

#### 3. Securing the Box:

- ▶ Use Confirmat Screws (A) to fasten the Box Side (4) to the Box Bottom (5).



#### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**

Excessive water will cause damage, voiding the warranty.