



EVERY 2 Drawer

Parts List - (16 Parts)

1. Left Side x1	4. Top x1	7. Drawer Sides x4
2. Right Side x1	5. Drawer Bottom x2	8. Drawer Rear x2
3. Bottom x1	6. Drawer Front x2	9. Cleat x1
		10. Backing 3mm x1



Body Assembly

- Screw Cam Pin (D) into Top Panel(4)
- Insert Cams (C) into big holes on Side Left (1) and Side Right (2) with arrows facing outside holes.
- Attach Drawer Runners (B) to sides (1, 2) where marked using 12 Flat Screws supplied.
- Screw in Cam Pin (D) into small holes on sides (1,2) where the Cleat(9) is going to go.
- Screw Bottom Panel (3) to Sides (1,2) using Confirmat Screws (A) with supplied Allen Key.
- Position Cleat (9) between sides (1, 2) Guide dowels to fit into 8mm holes and tighten Cams (C)
- Insert Backing 3mm(10) into back grooves of the cabinet
- Secure Top Panel (4) to sides (1, 2) using Cams - Do not use excessive force.
- Attach Cone Legs (F) to Bottom Panel(3) with provided screws.



Drawer Assembly

- Place Drawer Front (6) (holes facing up) on a soft surface. Insert Cam Pins (D) into the small holes on Front(6) and Sides (7) using a Phillip Screwdriver.* (not included)
- Insert Cams (C) into large holes on drawer sides (7) and Drawer Rear(8)
- Attach the Drawer Sides (7) to the Front (6) using Cams (C) - DO NOT Overtighten. .
- Slide Drawer Bottom (5) into the grooves.
- Position Drawer Rear (8) between the sides (1,2), over the cam pins and tighten Cams (C).
- Fix Handle (E) with supplied screws.
- Slide the Drawer into the main body by tilting it at a downward angle, ensuring the wheels fit INSIDE the guides on the sides of the body.

Hardware

A	Confirmat Screws (use supplied Allen Key)	x 4	
B	Drawer Runner Set 350mm Flat Runner Screws	x 2 x 12	
C	Cams	x 14	
D	Cam Pins	x 14	
E	Pull Handle Black Screws (4 x 16)	x 2 x 4	
F	Cone Leg H200 Black G-Screws	x 4 x 16	



There we go! You are all done. Congratulations !

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.