



me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS



ALASKA WARDROBE

Parts List (22 parts)

1. Top	x 1	8. Drawer Front	x 2
2. Bottom	x 1	9. Drawer Side	x 4
3. Side Right	x 1	10. Drawer Rear Side	x 2
4. Side Left	x 1	11. Door Left	x 1
5. Cleat	x 1	12. Door Right	x 1
6. Shelf with Dowels	x 1	13. Backing 3mm	x 1
7. Drawer Bottom 3mm	x 2	14. Adjustable Shelves	x 3

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 12	
B	Allen Key	x 1	
C	Cam Screws	x 10	
D	Cam Pins (using a Phillips Screwdriver (⚡) - <i>not supplied</i>)	x 10	
E	Pothole Screws (3 x 16 silver-plated)	x 36	
F	Pothole Hinges	x 6	
G	Duplo Shelf Studs	x 12	
H	Pair Roller Runners (Pre-fitted to Drawer and Cupboard sides)	x 2	
I	Handle 160mm Handle 96mm	x 2 x 2	
J	Bun Feet	x 4	
K	Self-tapping Screws	x 4	
L	Backing Screws	x 29	



CLEANING INSTRUCTIONS
NB: Clean with a damp cloth only.
 Excessive water will cause damage, voiding the warranty.





ALASKA WARDROBE



Body Assembly

1. Sides, Shelf & Cleat Setup:

- ▶ Lay the Side Left (4) and Right (3) on a soft surface with holes facing upwards.
- ▶ Screw Cam Pins (D) to the sides (3 & 4) where marked for Shelf (6) & Cleat (5). Insert Cams (C) into the large holes on Cleat (5) and Shelf (6) ensuring the arrow faces the nearest side.
- ▶ Position the Shelf (6) and Cleat (5) over the Cam Pins (D) and tighten. Then, position the other side on top and tighten.

2. Top & Bottom Setup:

- ▶ Use Confirmat Screws (A) to attach the Bottom (2) and Top (1) to the sides of the wardrobe.

3. Final Touches:

- ▶ Attach Bun Feet (J) using Self Tapping Screws (K) in the small holes below the bottom.
- ▶ Secure the Backing (13) to the back of the unit using Small Brass Screws (L). Stand the cupboard on its feet.
- ▶ Attach Hinges (F) to Doors using Screws (E). Attach Handles (H) 160mm to doors (11 & 12) & 96mm to Drawers (8).
- ▶ Fit Doors (11 & 12) to the Cupboard. Adjust doors to hang straight using the adjustment screw on the hinge.
- ▶ Insert 12 Shelf Studs (G) in the provided holes inside the wardrobe at your desired height. Place Shelves (14) on top.
- ▶ Tilt the assembled drawer at a downward angle and slide it into the main unit. Do the same for the second drawer.



Drawer Assembly

1. Drawer Front Setup:

- ▶ Lay the Drawer Front (8) upside down on a soft surface (e.g., blanket).
- ▶ Screw Cam Pins (D) into the Drawer Front using a Phillips Screwdriver (⊕)*

* Not Supplied

2. Drawer Sides and Bottom Setup:

- ▶ Insert Cams (C) into Drawer Sides (9).
- ▶ Attach Drawer Sides to the Front using Cams (C) – do not over-tighten.
- ▶ Slide the Drawer Bottom (7) into its groove.
- ▶ Secure the Drawer Rear (10) to the assembly using Confirmat Screw (A).

