










AVA KARLSTAD DRAWER UNIT

Parts List (20 parts)

1. Left Side	x 1	6. Drawer Front	x 3
2. Right Side	x 1	7. DrawerSides	x 6
3. Bottom Panel	x 1	8. Drawer Rear	x 3
4. Top Panel	x 1		
5. Backing 3mm	x 4		

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver.

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 10	
B	Allen Key	X 1	
C	Cams	X 10	
D	Cam Pins	X 10	
E	Set 350 Runner Runner Screws	X 3 X 18	
F	Pull Handle Handle Screws	X 1 X 3	
G	Black & Gold Leg G Screws	X 4 X 16	



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS



AVA KARLSTAD DRAWER UNIT



Body Assembly

- ▶ Begin with Top Panel (4), lay it upside down on a soft surface and screw in the Cam Pins (D) into the small holes.
- ▶ Lay down the Sides (1 & 2) and attach the Drawer Runners (E) to both Side Panels. Insert the Cams (C) into the large holes, make sure the arrow on the cam faces the nearest side.
- ▶ Attach the prepared Side Panels (1 & 2) to the Top Panel (4) and tighten the Cams.
- ▶ Slide backing (5) into the grooves from the top making sure it is in the groove from top to bottom.
- ▶ Place Bottom Panel (3) onto the main body.
- ▶ Insert Conformat Screws (A) and tighten.
- ▶ Place the legs (G) to the Bottom Panel (3) and fasten with supplied screws.



Drawer Assembly

1. Drawer Front Setup:

- ▶ Lay the Drawer Fronts (6) on a soft surface.
- ▶ Screw 2 Cam Pins (D) into the small holes.

2. Drawer Sides & Backing Installation:

- ▶ Insert Cams (C) into Drawer Sides (7) and place Drawer Sides into Drawer Front (6) ensuring dowels fit into the holes. Then tighten Cams (C).
- ▶ Slide the Drawer Bottom (5) into the grooves.

3. Drawer Rear Attachment:

- ▶ Slide Drawer Rear (8) into the sides ensuring the dowels fit into the holes. Then secure with Conformat Screws (A).
- ▶ Fit handles (F) with supplied screws.

REPEAT PROCESS FOR ALL DRAWERS

- ▶ Slide the assembled Drawers into the main body at a downward angle ensuring the wheels run inside the guides on the sides of the body.

There we go! You are all done. Congratulations!

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



mecofurniture.co.za