










BROOKLYN HEADBOARD SINGLE

Parts List (17 Parts)

1. Left Post	x1	4. Horizontal Slats	x9
2. Right Post	x1	5. Top Panel	x1
3. Top & Bottom Cleat	x2	6. Backing 3mm	x3

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 2	
B	Allen Key	x 1	
C	Brown Glides (Attached to parts, no action needed)	x 2	
D	Cams	x 4	
E	Cam Pins	x 4	
F	Screws (4x16)	x 30	
G	Cover Stickers	x 3	



Unit Assembly

1. Post Setup:

- ▶ Lay the Left & Right Post (1 & 2) on a soft surface with drilling holes facing upwards.
- ▶ Screw in the Cam Pins (E) into the Posts using a Phillips Screwdriver (⚙️)*

* Not Supplied

2. Cleat Installation:

- ▶ Insert Cams (D) into the Cleats (3), ensuring the arrow on the screw is facing the outside holes.
- ▶ Attach the Cleat (3) over the pins on the Posts (1 & 2) and tighten using a Phillips Screwdriver (⚙️)*
- ▶ Avoid using excessive force.

* Not Supplied

3. Slat Placement:

- ▶ Lay the Slats marked (4) face down in the opening.
- ▶ Make sure to place the slats with flat bottoms on either the top or bottom of the opening.

4. Back Panel Attachment:

- ▶ Identify the Backing marked (6) and align it with the marking on the posts at the back of the headboard.
- ▶ Use the Screws (F) to secure the Backing (6) over the Slats.

5. Final Assembly:

- ▶ Stand the headboard in an upright position.
- ▶ Attach the Top Panel (5) to the main body using the Confirmat Screws (A) and the supplied Allen Key (B).
- ▶ Use the Cover Stickers (G) to conceal the heads of the Confirmat Screws (A).

