








## CHARLIE COFFEE TABLE

### Parts List (19 parts)

1. Top	x 1	7. Drawer Front	x 2
2. Bottom	x 1	8. False Drawer Front	x 2
3. Side Left	x 1	9. Drawer Side Left	x 2
4. Side Right	x 1	10. Drawer Side Right	x 2
5. Division	x 1	11. Drawer Rear	x 2
6. Drawer stretcher	x 2	12. Drawer Bottom 3mm	x 2

### Hardware

<b>A</b>	Confirmat Screws (use the supplied Allen Key)	x 6	
<b>B</b>	Allen Key	x 1	
<b>C</b>	Cams	x 17	
<b>D</b>	Cam Pins	x 17	
<b>E</b>	Drawer Runner Set 450mm Screws (6 x 16)	x 2 x 16	
<b>F</b>	Bunfoot Screws (8 x 40)	x 4 x 4	
<b>G</b>	Pull Handle Black 110mm Screws (4 x 16)	x 2 x 4	

Before you begin, make sure you have all the parts listed in the assembly guide and organise them by type and size. You will also need a star or Philip's screwdriver, and an allen key will be provided



### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**

Excessive water will cause damage, voiding the warranty.



## CHARLIE COFFEE TABLE



### Body Assembly

- ▶ Start by fastening all 2 of the Runners (E) with supplied screws to the sides (3,4) and Division (5)
- ▶ Place Top (1) with pinholes upwards. Screw 9 x Cam Pins (D) into small holes on Top (1) and Insert Cams (C) into big drill holes on Sides (3,4) and Division (5) with arrows on Cams facing upwards.
- ▶ Attach Side Left (3) by sliding the Cam Pin (D) (*attached to the Top*) through the holes in Side Left (3). Do not tighten Cams at this stage.
- ▶ Attach Division (5) by sliding the Cam Pin (D) attached to the top through the holes in Side Left (3). Do not tighten Cams (C) at this stages
- ▶ Move Drawer Stretcher with False Front pre-assembled (6,7) in between Side Left (3) and Division (5) so that dowels insert into drilled holes.
- ▶ Attach Side Right (4) by sliding the Cam Pins (D) attached to the top through the holes in Side Right (4). Do not tighten Cams (C) at this stage.
- ▶ Move Drawer Stretcher with False Front pre-assembled (6,7) in between Side Right (4) and Division (5) so that dowels insert into drilled holes. The Cams (C) can be tightened after this has been done.
- ▶ Place Bottom (2) so that the holes align with the inserted dowels on Sides and Division (3,4,5). Fasten the Bottom (2) with Confirmat Screws (A) and supplied Allen Key (B)
- ▶ Fasten Bunfeet (F) with the supplied screws. The Unit can be turned right side up after this.



### Drawer Assembly

- ▶ Place Drawer Front (7) upside down on soft surface. Screw Cam Pins (D) into small holes on Front and Sides (9,10) using a Phillips Screwdriver.
- ▶ Insert Cams (C) into Large holes on Drawer Sides (9,10) and Drawer Rear (11)
- ▶ Fit Drawer sides to Drawer Rear using Cams (C) - Do not over tighten. Slide Drawer Bottom (12) into groove. Slide Drawer Front over Cam Pins (D) on sides and tighten Cams.
- ▶ Attach Handle (G) to back of Drawer Front using the supplied Screws.
- ▶ Slide Drawer into main body by tilting on a downward angle - Make sure wheels are running **inside** the guides on the sides of the body.