



me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS



DEXTER DESK


Parts List (16 parts)

1. Top	x 1	7. Drawer Backing 3mm	x 2
2. Side Left	x 1	8. Drawer Front	x 2
3. Side Right	x 1	9. Drawer Side Left	x 2
4. Shelf	x 1	10. Drawer Side Right	x 2
5. Division	x 1	11. Drawer Rear	x 2
6. Cleat	x 1		

Before you begin make sure you have all the parts listed and organise them by type and size

Hardware

A	Confirmat Screws 50 mm (Use the supplied Allen Key)	x 7	
B	Confirmat Screws 70 mm (Use the supplied Allen Key)	x 8	
C	Cams	x 16	
D	Cam Screw	x 16	
E	Set of 2 Metal Drawer Runner 450mm Screws (6 x 16)	x 2 x 12	
F	Pull Handle Black Screws (4 x 16)	x 2 x 4	
G	Stickers	x 8	



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



DEXTER DESK



Unit Assembly

- ▶ Place **Top Panel (1)** upside down on a soft surface. Screw 12 x Cam Screw (D) into small holes using Phillips Screwdriver.ⓘ
- ▶ **Place Sides (2,3)** down. Attach Drawer Runners (E) - Refer to the drawing on the sides. Ensure that all screw heads are flush and not angled or protruding. Do the same for both sides of the Division (5).
- ▶ Push Cams (C) into big holes on the **Division (5)** and **Both Sides (2,3)** and **Cleat (6)** with the arrow on the Cam facing down.
- ▶ Place Sides and Division over Cam Screws but do not yet tighten.
- ▶ Slide **Cleat (6)** between the Sides so that the wooden dowels fit into the marked holes.
- ▶ Slide **Shelf (4)** between the Sides onto the Division so that the wooden dowels fit into the marked holes.
- ▶ Use the 70mm Confirmat Screws (B) and screw from the outside of the Sides (2,3) into the Cleat (6) and Shelf (4)
- ▶ Use the **50mm** Confirmat Screws (A) and screw through the cleat into the shelf (1 x Confirmat) and through the shelf into the Division (2 x Confirmat)
- ▶ Tighten all the Cams (4 on each side and 2 on the Division)
- ▶ Flip Desk over so it stands on it's legs.



Unit Assembly

- ▶ Place **Drawer Front (8)** upside down on a soft surface.
- ▶ Screw Cam Screws (D) into the small holes on Front (8)
- ▶ Fit **Drawer Sides (9,10)** to Front over the Pins on the Front and tighten.
- ▶ Fix **handle (F)** with supplied screws.
- ▶ Slide **Drawer Backing 3mm (7)** into grooves.
- ▶ Fit **Drawer Rear (11)** between sides - make sure Foil Backing is in groove. Use 2 x Confirmat Screws to fix Drawer Rear to Drawer Sides.
- ▶ Slide Drawer into main body by tilting on a downward angle.

There we go! You are all done. Congratulations !

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.