

ASSEMBLY INSTRUCTIONS

JAKE BEDSIDE TABLE

Parts List (18 parts)

5. Top Panel

1. Left Side **6.** Backing 3mm x 2 2. Right Side хl 7. Drawer Front χl **3.** Floating Shelf Drawer Sides хl 8. x 2 4. Bottom Panel хl Drawer Rear x 2

хl

Hardware

Α	Confirmat Screws (use the supplied Allen Key)	x 6	*
В	Allen Key	×Ί	٢
С	Cams	x 6	*
D	Cam Pins	x 6	i e
E	Set 350 Runner & Screws	x1 x6	
F	Pull Handle & Screws	x1 x2	No.
G	30mm Bun Feet & Screws	x 4 x 4	© 1
н	Shelf Studs	x 4	







ASSEMBLY INSTRUCTIONS

JAKE BEDSIDE TABLE



Body Assembly

Top Panel Setup:

- Lay the Top Panel (5) on a soft surface with drill holes facing up.
- Screw 4 Cam Pins (D) into the small holes using a Phillips screwdriver (♠)*
- * Not Supplied

2. Sides & Runner Installation:

- Insert Cams (C) into the large drill holes on Sides (1 & 2) with arrows on the Cams pointing towards the drill holes.
- Attach Drawer Runners (E) to the Sides using the FLAT screws provided.

3. Sides & Top Panel Attachment:

Position the Sides over the Cam Pins on the Top Panel and tighten (avoid using excessive force).

4. Backing Installation:

Slide the Backing 3mm (6) into the groove on the sides, ensuring it also slides into the groove on the Top Panel.

5. Bottom Panel & Bun Feet Attachment:

- Position the Bottom Panel (4) ensuring the Backing 3mm
 (6) slides into its groove.
- Use 4 Confirmat Screws (A) and the provided Allen Key (B) to attach the Bottom to the body of the Pedestal.
- Attach the Bun Feet (G) to the Bottom using the LONG screws.

6. Floating Shelf Installation:

Insert the Shelf Studs (H) into the Sides and position the Floating Shelf (3) in place.



Drawer Assembly

1. Drawer Front Setup:

- Lay the Drawer Front (7) on a soft surface.
- Screw 2 Cam Pins (D) into the small holes.

2. Drawer Sides & Backing Installation:

- Attach the Drawer Sides (8) over the pins on the Front and tighten.
- ▶ Slide the Drawer Backing (6) into its grooves.

3. Drawer Rear Attachment:

- Position the Drawer Rear between the sides, ensuring the Foil Backing fits into its groove.
- Use 2 Confirmat Screws to secure the Drawer Rear to the Drawer Sides.

4. Drawer Installation:

Slide the Drawer into the main body at a downward angle, ensuring the wheels run inside the guides on the sides of the body.



