



**me&co**  
QUALITY, AFFORDABLE FURNITURE

# ASSEMBLY INSTRUCTIONS



## KIDS DOUBLE STORAGE

### Parts List (9 parts)

1. Top Panel	x 1	8. Leg Right	x 1
2. Bottom Panel	x 1	9. Cleat	x 1
3. Back	x 1		
4. Side Left	x 1		
5. Side Right	x 1		
6. Division	x 1		
7. Leg Left	x 1		

### Hardware

<b>A</b>	Confirmat Screws (Use the supplied Allen Key)	x 9	
<b>B</b>	Furniture Screws	x 8	
<b>C</b>	Cams	x 15	
<b>D</b>	Cam Pins	x 15	



### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**


Excessive water will cause damage, voiding the warranty.



## KIDS DOUBLE STORAGE



### Unit Assembly

- ▶ Position the **Top Panel (1)** upside down on a soft surface. Insert 9 Cam Pins (**D**) into the small 5mm holes on the Top Panel (1). 
- ▶ Insert 3 Cam Pins (**D**) into the small 5mm holes on the **Left Side (4)**. Place 2 Cams (**C**) into the larger 15mm holes.
- ▶ Insert 3 Cam Pins (**D**) into the small 5mm holes on the Right Side (5). Fit 2 Cams (**C**) into the larger 15mm holes.
- ▶ Fit 7 Cams (**C**) into the larger 15mm holes on the Back (3).
- ▶ Fit 2 Cams (**C**) into the larger 15mm holes on the Cleat (8).
- ▶ Hold the **Back (3)** on its long side, ensuring the larger holes are facing up.
- ▶ Attach the **Right Side (5)** to the **Back (3)** by inserting the Cam Pins into the small holes at the edge of the Back (3). Ensure that the dowels align with the 8mm holes and push inward.
- ▶ Repeat the process with the **Left Side (4)** on the opposite side of the Back.
- ▶ Position the **Cleat (8)** (with larger holes facing backward) at the lower part on the opposite side, between the Sides (4, 5).
- ▶ Tighten the Cams using a Phillips screwdriver at the Back and Cleat.
- ▶ Place the assembly over the Top, ensuring the Cleat is on top, and tighten all the cams.



### Unit Assembly

- ▶ Take Division (6) with the double dowels facing downward. Slide it down the middle from the top side, ensuring the dowels fit into the holes and pins.
  - ▶ Tighten all Cams using a Phillips screwdriver.
  - ▶ For the Bottom (2), hold it so that the fewest holes are facing upwards. Place it over the Box, ensuring the dowels fit properly. Confirm that the Partition also fits into the dowel holes.
  - ▶ Use 9 Confirmat Screws (A) to secure everything in place with the Allen key.
- Legs (7)** - Ensure the legs are positioned to the side (most holes should be at the bottom). Align them with the four visible holes on the box, and use the provided furniture screws to secure them to the box with the Allen key.

**There we go! You are all  
done. Congratulations!**

#### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**

Excessive water will cause damage, voiding the warranty.