



**me&co**  
QUALITY, AFFORDABLE FURNITURE

# ASSEMBLY INSTRUCTIONS



## KIDS ROBE

### Parts List (15 parts)

1. Left Side	x 1	8. Backing 3mm	x 1
2. Right Side	x 1	9. Solid Triangular Panel	x 1
3. Divider Between Drawers	x 1	10. Roof	x 2
4. Bottom Panel	x 1	11. Drawer Front	x 4
5. Mid Shelf	x 1	12. Drawer Side Left With Runner Strip	x 4
6. Top Shelf	x 1	13. Drawer Side Right With Runner Strip	x 4
7. Nailers Horizontal Support	x 3	14. Drawer Rear	x 4
		15. Drawer Bottom	x 4

### Hardware

<b>A</b>	Confirmat Screws (Use the supplied Allen Key)	x 12	
<b>B</b>	Drywall Screws (6 x 28)	x 6	
<b>C</b>	Cams	x 32	
<b>D</b>	Cam Pins	x 32	
<b>E</b>	Cone Pine Leg 100mm	x 4	
<b>F</b>	Pan Head Screws	x 4	
<b>G</b>	Oval Rail	x 1	
<b>H</b>	Metal Brackets ( For Oval Rail)	x 2	
	Screws (6 x 16)	x 4	
<b>I</b>	Cover Stickers	x 12	



**Before you begin make sure you have all the parts listed and organise them by type and size**



**Safety Tip:**  
To ensure your children's safety, please use safety brackets and Hilti anchors to secure the unit and prevent it from tipping over.

### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**

Excessive water will cause damage, voiding the warranty.



## KIDS ROBE



### Unit Assembly

**Do NOT use force to fit anything on this Build**

- ▶ Position the Sides (1, 2) on a soft surface, ensuring the drill holes are facing upwards. Secure 14 Cam Pins (D) into the small holes using a Phillips screwdriver (not included).
- ▶ Insert the Cams (C) into the Top Shelf (6), Mid Shelf (5), and Nailers (7), making sure the arrows on the Cams point towards the outer holes.
- ▶ Slide the Mid Shelf, Top Shelf, and Nailers over the Pins on the Sides, then tighten them with a screwdriver.
- ▶ Place the Divider (3) between the Mid Shelf (5) and the Bottom (4), and secure it using the Cams.
- ▶ Attach the Cone Legs (E) to the Bottom (4) with Pan Head Screws (F) and an Allen Key. Ensure the Cone Legs are not placed on the grooved side of the Bottom.
- ▶ Insert the Foil Backing (8) into the grooves between the Nailers until it fits securely in the Bottom Groove.
- ▶ Fasten the Bottom (4) to the Sides (1, 2) and the Divider (3) using Confirmat Screws (A) from the bottom.
- ▶ Construct the roof structure using Confirmat Screws (A). This is best achieved by placing the Roof Pieces (10) on their sides and securing the top Confirmat Screws first. Then, attach the Triangular Panel (9) and insert Confirmat Screws through the roof, tightening them with an Allen Key.
- ▶ Position the completed roof structure on top of the main body and secure it with Drywall Screws (B), taking care not to drive the screws in too deeply. Finish the assembly with the supplied Cover Stickers (I).
- ▶ Attach the Oval Rail Brackets (H) to the Sides using 4 screws, then slide the Oval Rail (G) into the Brackets.



### Drawer Assembly

**Be careful not to drop sides with Runners or Bend metal strips**

- ▶ Place the Drawer Front (11) on a soft surface. Secure the Cam Pins (D) into the 5mm holes on the Drawer Sides (12,13).
- ▶ Insert the Cams (A) into all larger holes on the Drawer Parts, ensuring the arrow markings are facing outward from the drill holes.
- ▶ Slide the Drawer Rear (14) over the Pins on the Sides and tighten using a screwdriver. Ensure the grooves are properly aligned.
- ▶ Slide the Drawer Bottom (15) into the grooves.
- ▶ Fit the structure over the Pins on the Drawer Front (11) and align the grooves. Tighten the Cams securely.
- ▶ Slide the Drawer into the main body by carefully aligning Drawer Slides with centers of Drawer Runners on Main Body of Robe, then push it forward slowly.

#### Take Note:

**Drawers can ONLY be removed by pressing small plastic levers on the slides, One UP, One Down**

**There we go! You are all done. Congratulations !**

#### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**

Excessive water will cause damage, voiding the warranty.