










## LISBON 2 DRAWER

### Parts List (16 parts)

1. Left Side	x 1	7. Drawer Sides	x 4
2. Right Side	x 1	8. Drawer Rear	x 2
3. Bottom Panel	x 1	9. Cabinet Backing	x 1
4. Top Panel	x 1	10. Fixed Shelf	x 1
5. Drawer Bottom 3mm	x 2		
6. Drawer Front	x 2		

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver.

### Hardware

<b>A</b>	Confirmat Screws (use the supplied Allen Key)	x 6	
<b>B</b>	Allen Key	x 1	
<b>C</b>	Cams	x 22	
<b>D</b>	Cam Pins	x 22	
<b>E</b>	Runners 350mm Set	x 2	
<b>F</b>	Runner Screws (6 x16)	x 16	
<b>G</b>	Brown Cone Legs with supplied screws	x 4	



### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**

Excessive water will cause damage, voiding the warranty.



## LISBON 2 DRAWER



### Body Assembly

- ▶ Screw Cam Pins (D) into Bottom Panel (3), Side Left (1) and Side Right (2).
- ▶ Insert Cams (C) into big holes on Cabinet Backing (9), Fixed Shelf (10) and Top (4) with small arrows on Cams facing outside holes.
- ▶ Attach Drawer Runners (F) to Side Left (1) and Side Right (2) using Phillips Screwdriver - see markings on side for position of runners.
- ▶ Connect the Top (4) and Cabinet Backing (9) with supplied dowels and slightly turn in the Conformat Screws (A) through the Cabinet Backing into the Top, creating a L-Shape. The big holes in top should be facing to the right (bottom when the unit is upright) The big holes in the Cabinet Backing should be facing the back.
- ▶ Place Side Left (1) on a soft surface with cam pins facing upwards and rounding on the corner facing you. Locate assembly over cam pins, ensuring pins and dowels line up with their respective holes.



### Body Assembly

- ▶ Locate Fixed Shelf (10) over Cam Pins. Cam holes in Fixed shelf should also be facing to the right. The Cams can be tightened at this stage.
- ▶ Orientate Side Right (2) so that the Cam Pins (D) face downward and fit Cam Pins and Dowels into the holes on the fixed shelf, cabinet backing and top. Securely fasten cam screws.
- ▶ Fit Legs (G) to the Bottom Panel (3) with screws provided by screwing through the Bottom Panel into the Leg.
- ▶ Turn assembly upside down and fit Bottom with Legs pointing upwards over dowels and cam pins.
- ▶ Tighten Conformat Screw (A) with provided Allen Key (B) and fasten Cams on Cabinet Backing (9). Tighten Conformat Screws (A) through Cabinet Backing (9) into Top (4)
- ▶ Turn assembly onto its Legs. It is now ready to accept the drawers.



### Drawer Assembly

- ▶ Lay the Drawer Front (6) upside down on a soft surface.
- ▶ Screw Cam Pins (D) into small holes on Front (6) and Sides (7) using Phillips Screwdriver.
- ▶ Insert Cams (C) into large holes on Drawer Sides (7) and Drawer Rear (8)
- ▶ Fit Drawer Sides (7) to Drawer Rear (8) using Cams. - **Do not over-tighten.**
- ▶ Slide Drawer Bottom (5) into Groove. Slide drawer Front (6) over Cam Pins on sides (7) and tighten Cams.
- ▶ Slide the Drawer into the main body by tilting at a downward angle, ensuring the wheels run **inside** the guides on the sides of the body.



SCAN TO WATCH VIDEO