



LOLA WARDROBE

Parts List (13 parts)

1. Top	x 1	8. Drawer Front	x 2
2. Bottom	x 1	9. Drawer Side	x 4
3. Side Right	x 1	10. Drawer Rear Side	x 2
4. Side Left	x 1	11. Door Left	x 1
5. Cleat	x 1	12. Door Right	x 1
6. Shelf	x 1	13. Backing Cover 3mm	x 1
7. Drawer Bottom 3mm	x 2		

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 12	
B	Allen Key	x 1	
C	Cams	x 10	
D	Cam Pins	x 10	
E	Pothole Screws	x 36	
F	Pothole Hinges	x 6	
G	Oval Tubing Brackets	x 2	
H	Oval Tubing	x 1	
I	Pothole Screws	x 4	
J	Handles 160mm, Handles 96mm	x 2 x 2	
K	Pair Roller Runners	x 2	
L	Flat Runner Screws	x 12	
M	Screws (4x16)	x 12	
N	Bun Feet	x 4	
O	Self Tapping Screws	x 4	
P	29 x Backing Screws		



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.





LOLA WARDROBE



Cupboard Assembly

1. Sides Setup:

- ▶ Lay side left (4) and right (3) on a soft surface with holes facing up.
- ▶ Attach the Rollers on the bottom side of the robe using flat screws.
- ▶ Screw Cam Pins (D) to the sides where marked for Shelf (6) & Cleat (5).
- ▶ Insert Cams (C) into Shelf (6) and Cleat (5) ensuring the arrow faces the nearest side.

2. Shelf and Cleat Installation:

- ▶ Position the Shelf (6) and Cleat (5) over the Cam Pins (D) and tighten.
- ▶ Place the other side on top (aligning pins with holes) and tighten.

3. Top and Bottom Panel Attachment:

- ▶ Use Confirmat Screws (A) to attach the Bottom (2) and Top (1) to the sides using the supplied Allen Key.

4. Bun Feet Installation:

- ▶ Attach Bun Feet (K) using Self Tapping Screws (L).

5. Backing Installation:

- ▶ Secure the Backing (13) to the back of the unit using Small Brass Screws (M).
- ▶ Lift the cupboard onto its feet.

6. Door Hinges and Handles Setup:

- ▶ Fit Hinges (F) to the Doors using Screws (E).
- ▶ Attach Handles (I) 160mm to the Doors.
- ▶ Secure the Oval tubing and brackets into Sides (1 & 2).
- ▶ Tilt the assembled drawer at a downward angle and slide it into the main unit. Do the same for the second drawer.

7. Door Installation:

- ▶ Fit Doors (11 & 12) to the Cupboard, aligning the hinges with the small holes and tighten securely. Adjust the Doors to hang straight using the Adjustment Screw on the Hinge.



Drawer Assembly

1. Drawer Front Setup:

- ▶ Lay the Drawer Front (8) upside down on a soft surface (e.g., blanket).
- ▶ Screw Cam Pins (D) into the Drawer Front using a Phillips Screw driver (⊕)*
- ▶ Insert Cams (C) into Drawer Sides (9).

* *Not Supplied*

2. Drawer Sides and Bottom Setup:

- ▶ Attach Drawer sides to the Front using Cams. NB – do NOT over-tighten.
- ▶ Slide the Drawer Bottom (7) into its groove.
- ▶ Secure the Drawer Rear (10) to the assembly using Confirmat Screws (A).

3. Drawer Handle Installation:

- ▶ Attach Handles (I) 96mm to the Drawer Front.

meco in

