



LONDON KARLSTAD DRAWER UNIT

Parts List (27 parts)

1. Left Side	x 1	6. Backing 3mm	x 2
2. Right Side	x 1	7. Drawer Front	x 4
3. Top Panel	x 1	8. Drawer Sides Left	x 4
4. Bottom Panel	x 1	9. Drawer Sides Right	x 4
5. Division	x 1	10. Drawer Rear	x 4
		11. Drawer Bottom 3mm	x 4

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 14	
B	Allen Key	X 1	
C	Cams	X 14	
D	Cam Pins	X 14	
E	Set 350 Runner Runner Screws	X 4 X 24	
F	Pull Handle Handle Screws	X 1 X 2	
G	Black Gold Legs G Screws	X 4 X 12	
H	Screw Caps	X 16	



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS



LONDON KARLSTAD DRAWER UNIT



Body Assembly

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver.



- ▶ Begin with Top Panel (3), lay it upside down on a soft surface and screw in the Cam Pins (D) into the small holes.
- ▶ Prepare the Division (5) and Side Panels (1 & 2) by inserting the Cams (C) into the large holes, make sure the arrow on the cam faces the nearest side.
- ▶ Attach the prepared Division (5) and Side Panels (1 & 2) to the Top Panel and tighten using the Cam Pins(D).
- ▶ Slide backing (6) into the grooves from the top making sure it is in the groove from top to bottom.
- ▶ Attach drawer runners (E) to Division (5) and Side Panels (1 & 2)
- ▶ Place Bottom Panel (4) onto the main body ensuring dowels fit into the holes.
- ▶ Insert Confirmat Screws (A) and tighten.
- ▶ Fit the legs (G) to the Bottom Panel (4), no closer than 180mm from the side and no closer than 30mm from the front and the back.



Drawer Assembly

1. Drawer Front Setup:

- ▶ Lay the Drawer Fronts (7) on a soft surface.
- ▶ Screw 2 Cam Pins (D) into the small holes.

2. Drawer Sides & Backing Installation:

- ▶ Insert Cams (C) into Drawer Sides (8 & 9) and place Drawer Sides into Drawer Front (7) ensuring dowels fit into the holes. Then tighten Cams (C).
- ▶ Slide the Drawer Bottom (11) into the grooves.

3. Drawer Rear Attachment:

- ▶ Slide Drawer Rear (10) into the sides ensuring the dowels fit into the holes. Then secure with Confirmat Screws(A).
- ▶ Fit handles (F) with supplied screws.

REPEAT PROCESS FOR ALL DRAWERS

- ▶ Slide the assembled Drawers into the main body at a downward angle ensuring the wheels run inside the guides on the sides of the body.

There we go! You are all done. Congratulations!

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



mecofurniture.co.za