



MONTGOMERY CABINET











Parts List (15 parts)

1. Left Side	x 1	6. Wine Rack Large	x 2
2. Right Side	x 1	6. Wine Rack Small	x 3
3. Bottom Panel	x 1	7. Left Shelf	x 1
4. Top Panel	x 1	8. Right Shelf	x 1
5. Backing 3mm	x 1	9. Division	x 1
Note: 3 Holes punched down centre.		10. Doors	x 2

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver.



Hardware

A	Conformat Screws (use the supplied Allen Key)	X 6	
B	Allen Key	X 1	
C	Cams	X 10	
D	Cam Pin	X 10	
E	Hinge (Ferrari Type 185°) Ferrari Screws (8 x 16)	X 4 X 24	
F	Gold Knurled Knob Screws	X 2 X 2	
G	Trident Black & Gold Legs G-Screws(9 x 16)	X 4 X 16	
H	Glass Rack with Metal Ferrari Screws (8 x 16)	X 1 X 4	
I	Cnr Blocks Plastic with Cover Ferrari Screws (8 x 16)	X 4 X 16	
J	Backing Screws	X 3	



SCAN TO WATCH VIDEO

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



MONTGOMERY CABINET



Cabinet Assembly

Take Note! 2 Shelves included are marked 7 & 8

- ▶ Place Two Sides (1 & 2) on a flat surface with drill holes facing up and grooves next to each other. Top of Cabinet is where the 4 small marker holes are for the Corner Blocks (I)
- ▶ Screw 2 x Corner Blocks (I) into position using 2 x Ferrari Screws each. Corner Blocks sold side facing edge of Sides - The Top Panel (4) will rest on these blocks
- ▶ Screw Cam Pins (D) into middle of Sides using a Phillips Screwdriver - make sure to screw them in straight. Place Cams (C) in Shelves (7 & 8) with little arrow on the Cam facing the outer holes. Fit Left Shelf (7) and Right Shelf (8) over the Cam Pins on Side Left (1) and Side Right (2) and tighten with screwdriver - do not use excessive force.
- ▶ Flip the two Sides (1 & 2) and the Shelves (7 & 8) with grooves facing up.
- ▶ Attach Bottom Panel (3) with Conformat Screws (A) using the supplied Allen Key (B). Screws go right through Bottom Panel. Tighten until screws are level with surface. Make sure 16 x Marker holes for legs are Outside.
- ▶ Slide 3mm Backing (5) into groove - Black side facing down.
- ▶ Attach Top Panel (4) by sliding it over backing and secure with Ferrari Screws through Corner Blocks (I) - Make sure sides are pressed firmly against Gold Edging on the top before driving screw in.
- ▶ Attach Legs (G) to Bottom Panel using the supplied G- Screws (See marker holes)
- ▶ Attach Glass Rack (H) beneath the Top panel where you choose to.



Wine Rack & Doors Assembly

1. Wine Rack:

- ▶ Assemble Wine Rack (6) by sliding 3 x Small pieces over 2 x Large pieces
- ▶ Slide Wine Rack assembled into Left Side of the Cabinet

2. Doors:

- ▶ Attach Doors (10) - First attach Hinges to the Doors using Ferrari Screws. Screw on handles on the ribbed side and attach doors to main frame at indicated marker holes. Adjust Hinges slightly if floors are uneven to ensure the doors are hanging straight.

There we go! You are all
done. Congratulations !

Scan to
watch
assembly
video



SCAN TO WATCH VIDEO

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.