



MOTION BEDSIDE TABLE

Parts List

- | | | |
|------------------|--------------------|--------------------|
| 1. Left Side X1 | 4. Top Panel X1 | 7. Drawer Sides X4 |
| 2. Right Side X1 | 5. Backing 3mm X3 | 8. Drawer Rear X2 |
| 3. Bottom X1 | 6. Drawer Front X2 | 9. Cleat X1 |



Body Assembly

- ▶ Screw Cam Pin (D) into Top Panel (4). Insert Cam (C) into big hole on Side Left (1) and Side Right (2) with small arrows on Cam facing outside holes.
- ▶ Attach Drawer Runners (B) to Side Left and Side Right using Flat Screws provided - see markings on side for position of runners.
- ▶ Screw Bottom Panel (3) to Sides (1,2) using Confirmat Screws (A) with Allan Key Provided.
- ▶ Slide Cleat (9) in between Sides (1,2) so that the dowels align with the holes on the sides and insert and tighten Confirmat screws (A) from the outside of the sides.
- ▶ Insert Foil Backing (5) for cabinet into back grooves.
- ▶ Attach Top Panel to Sides(1,2) using Cams(C) - Do not use excessive force.
- ▶ Attach T-Legs (F) to the Bottom Panel (3) using the Supplied Screws.









Drawer Assembly

- ▶ Place Drawer Front (6) on soft surface. Screw Cam Pins (D) into small holes. Remember to attach handle after assembly.
- ▶ Fit Drawer Sides (7) over pins on Front and tighten.
- ▶ Slide Drawer Foil Backing (5) into grooves.
- ▶ Fit Drawer Rear (8) between sides (1,2) - make sure Foil Backing is in groove. Use 2 x Confirmat Screw (A) to fix Drawer Rear (8) to Drawer Sides (7)
- ▶ Slide Drawer into main body by tilting on a downward angle - Make sure wheels are running **inside** the guides on the sides of the body.

There we go! You are all done. Congratulations!

Hardware

A	Confirmat Screws Allen Key	x 10 x 1	
B	350mm Drawer Runner Sets Screws (6 x 16)	x 2 x 12	
C	Cam Screws	x 8	
D	Cam Pins	x 8	
E	Black Bar Handle 128mm Screws(4 x 16)	x 2 x 4	
F	Black Cone Leg 150mm G-Screws (9 x 16)	x 4 x 16	



SCAN TO WATCH VIDEO



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



MOTION BEDSIDE TABLE

Parts List

- | | | |
|------------------|--------------------|--------------------|
| 1. Left Side X1 | 4. Top Panel X1 | 7. Drawer Sides X4 |
| 2. Right Side X1 | 5. Backing 3mm X3 | 8. Drawer Rear X2 |
| 3. Bottom X1 | 6. Drawer Front X2 | 9. Cleat X1 |



Body Assembly

- ▶ Screw Cam Pin (D) into Top Panel (4). Insert Cam (C) into big hole on Side Left (1) and Side Right (2) with small arrows on Cam facing outside holes.
- ▶ Attach Drawer Runners (B) to Side Left and Side Right using Flat Screws provided - see markings on side for position of runners.
- ▶ Screw Bottom Panel (3) to Sides (1,2) using Confirmat Screws (A) with Allan Key Provided.
- ▶ Slide Cleat (9) in between Sides (1,2) so that the dowels align with the holes on the sides and insert and tighten Confirmat screws (A) from the outside of the sides.
- ▶ Insert Foil Backing (5) for cabinet into back grooves.
- ▶ Attach Top Panel to Sides(1,2) using Cams(C) - Do not use excessive force.
- ▶ Attach T-Legs (F) to the Bottom Panel (3) using the Supplied Screws.









Drawer Assembly

- ▶ Place Drawer Front (6) on soft surface. Screw Cam Pins (D) into small holes. Remember to attach handle after assembly.
- ▶ Fit Drawer Sides (7) over pins on Front and tighten.
- ▶ Slide Drawer Foil Backing (5) into grooves.
- ▶ Fit Drawer Rear (8) between sides (1,2) - make sure Foil Backing is in groove. Use 2 x Confirmat Screw (A) to fix Drawer Rear (8) to Drawer Sides (7)
- ▶ Slide Drawer into main body by tilting on a downward angle - Make sure wheels are running **inside** the guides on the sides of the body.

There we go! You are all done. Congratulations!

Hardware

A	Confirmat Screws Allen Key	x 10 x 1	
B	350mm Drawer Runner Sets Screws (6 x 16)	x 2 x 12	
C	Cam Screws	x 8	
D	Cam Pins	x 8	
E	Black Bar Handle 128mm Screws(4 x 16)	x 2 x 4	
F	Black Cone Leg 150mm G-Screws (9 x 16)	x 4 x 16	



SCAN TO WATCH VIDEO



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.