



NEO BEDSIDE TABLE

Parts List (21 x Parts)

1. Left Side	x 1	5. Backing 3mm	x 1	9. Drawer Sides Left	x 3
2. Right Side	x 1	6. Doweled Skirting	x 1	10. Drawer Sides Right	x 3
3. Bottom Panel	x 1	7. Drawer Front	x 3	11. Drawer Bottom 3mm	x 3
4. Top Panel	x 1	8. Drawer Rear	x 3		



Body Assembly

Do NOT use force to fit anything on this Build

► Begin by placing Top Panel (4) on a soft surface with the drill holes facing upwards. Using a Phillips screwdriver (*not included*), screw in 4 x Cam Pins (B) into the small holes.

► Prepare Both Sides (1, 2) by screwing the Cam Pins (B) into the 5mm holes and attaching the Drawer Runners (D) with the provided screws. Refer to the drawing on the sides. Ensure that all screw heads are flush and not angled or protruding.

► Insert Cams (A) into all large holes on each part, making sure the arrow markings face outward from the drill holes.

► Position Bottom (3) and Skirting (6) between Sides (1, 2), then tighten the Cams (A) using the Phillips screwdriver. Note that the Skirting has 2 Dowels that should fit into the holes on the sides. Ensure the groove on the Bottom aligns with those on the sides.

► Carefully slide the Backing 3mm (5) into the grooves on the Sides (1,2) and Bottom(3). Lift the structure gently to fit over the Cam Pins on the Top, ensuring that the grooves align and the Backing is seated deeply in the grooves. Finally, tighten the Cams.



Drawer Assembly

Be careful not to drop sides with Runners or Bend metal strips

► Place the Drawer Front (7) on a soft surface. Secure the Cam Pins (B) into the 5mm holes on the Drawer Sides (9,10).

► Insert the Cams (A) into all larger holes on the Drawer Sides(9,10), ensuring the arrow markings are facing the drill holes.

► Slide the Drawer Sides (9,10) over the Pins on the Rear (8)

► Slide the Drawer Rear (8) over the Pins on the Sides and tighten using a screwdriver. Ensure the grooves are properly aligned.

► Insert the Drawer Bottom (11) into the grooves.

► Fit the structure over the Pins on the Drawer Front (7) and align the grooves. Tighten the Cams securely.

► Attach the Handle (C) to the Drawer Front (7) using the provided screws.

► Slide the Drawer into the main body by tilting it at a downward angle, ensuring that the wheels are positioned inside the guides on the sides of the body.

Hardware

A Cams x 20



B Cam Pins x 20



C Pull Handle
Screws(4 x 16)
x 3
x 6



D 350mm Drawer Runner Sets
Screws (6 x 16)
x 3
x 18



There we go! You are all done.
Congratulations !

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.