



me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS



OPTIMA CABINET

Parts List (17 parts)

1. Top	x 1	9. Doors	x 2
2. Bottom	x 1	10. Backing 3mm	x 1
3. Side Right	x 1	11. Large Bottom Shelf	x 1
4. Side Left	x 1		
5. Division	x 1		
6. Shelves	x 5		
7. Cleats	x 2		
8. Top Cleat	x 1		

Hardware

A	Confirmat Screws <i>(use the supplied Allen Key)</i>	x 15	
B	Allen Key	x 1	
C	Cams	x 12	
D	Cam Pins	x 12	
E	Half Moon Handle with 4 x Screws	x 2	
F	Overlay Door Hinge Ferrari Screws	x 4 x 24	
G	G-Leg 350mm (2L+2R) Screws	x 4 x 8	
H	Ferrari Screws (8 x 16)	x 4	
I	Cover Stickers	x 8	



Scan to
watch
assembly
video



SCAN TO WATCH VIDEO

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



Scan QR Code - Follow video for precise assembly

1. Place the bottom panel (2) and right side panel (3) against each other in an L-shape and secure them using confirmat screws (A).
2. Screw cam pins (D) into the right side panel (3).
3. Lay down the right shelf panels (6) and screw in cam pins (D).
4. Slide the right shelf panels (6) into the division panel (5), ensuring the cam pins fit into the holes. Then tighten the cams.
5. Lay down the division panel (5) and screw in cam pins (D) on both sides.
6. Slide the division panel (5) into the right shelf panels (6) and tighten the cams.
7. Secure the division panel (5) to the bottom panel (2) using confirmat screws (A).
8. Lay down the left shelf panels (6) and insert cams (C).
9. Slide the left shelf panels (6) into the division panel (5), ensuring the cam pins fit into the holes. Then tighten the cams.
10. Attach the two back cleats (7) to the right side panel (3). Make sure the wooden dowels fit into the holes and secure with confirmat screws (A).
11. Lay down the left side panel (4) and screw in cam pins (D).
12. Flip the unit onto its right side.
13. Place the left side panel (4) onto the left shelf panels (6), ensuring the cam pins fit into the holes. Tighten the cams.
14. Secure the left side panel (4) to the bottom panel (2) with confirmat screws (A).
15. Slide the backing panel (10) into the designated grooves.
16. Lay the top panel (1) upside down and screw in cam pins (D).
17. Flip over the top panel (1) and attach the top trimming (8) using confirmat screws (A).
18. Place the top panel over the unit, ensuring the cam pins fit into the holes and tighten the cams (C).
Tip: If necessary, slightly loosen the confirmat screws (A) on the side panels to help align the top panel. Tighten them again once the panel is seated.
19. Secure the top panel (1) to the side panels (3,4) with confirmat screws (A).
20. Lay the door panels (9) upside down and attach the door hinges (F) to the inside of each panel.
21. Attach the door panels (9) to the inside of the unit by securing the hinges (F) to the side panels (3,4).
22. Attach the handles (E) to the outside of both doors (9).
23. Flip the unit upside down and attach the legs (G) with the provided screws.
24. Slide in the bottom shelf panel (11) and secure it with the provided screws.

There we go, setup is complete. Remember to use a damp cloth when cleaning. Avoid using excessive water as this may cause damage and void the warranty.

Thank you for choosing me&co!



SCAN TO WATCH VIDEO