



PARIS DRAWER UNIT

Parts List

1. Left Side X1	5. Backing 3mm X3	9. Cleat X1
2. Right Side X1	6. Drawer Front X3	10. Backing 3mm X1
3. Bottom X1	7. Drawer Sides X6	
4. Top X1	8. Drawer Rear X3	



Body Assembly








- Place Top Panel (4) upside down holes facing up
- Screw Cam Pin (D) into 4 small holes.
- Insert Cam (C) into 2 large holes on Side Left (1) and Side Right (2) with arrows facing nearest side.
- Attach 6 x Drawer Runners (B) to sides (1, 2) where marked using 18 x Flat Screws supplied.
- Attach Side Left (1) and Side Right (2) to Top Panel (4) with grooves aligning with the groove on the top.
- Position Cleat (9) below Top between sides (1, 2) Guide dowels to fit into 8mm holes and tighten Confirmat Screws (A) from outside
- Insert Foil Backing (10) into back grooves of the cabinet sure to fit in groove in the top
- Secure Bottom Panel (3) to sides (1, 2) (small holes facing upwards) with 4 x Confirmat Screws (A) using the Allen Key (B)
- Attach Top Panel to sides (1, 2) with Cams (C) carefully.
- Secure T-Legs (F) to Bottom Panel(3) aligning with the small guide holes in Bottom and fasten with provided screws.



Drawer Assembly

- Place Drawer Front (6) on a soft surface. Insert Cam Pins (D) into the small holes.
- Insert Cams (C) into big holes on drawer sides using Phillips screwdriver * (not included)
- Attach the Drawer Sides (7) over the pins on the Front (6) and tighten securely.
- Insert the Drawer Foil Backing (5) into the grooves.
- Position the Drawer Rear (8) between the sides (1,2), ensuring the Foil Backing is seated in the groove. Use 2 Confirmat Screws (A) to secure the Drawer Rear (8) to the Drawer Sides (7).
- Slide the Drawer into the main body by tilting it at a downward angle, ensuring the wheels fit inside the guides on the sides of the body.
- Don't forget to attach the handles (E) after assembly.

Hardware

A	Confirmat Screws (use supplied Allen Key)	x 12	
B	3 x Sets Drawer Runners with 18 x Flat Screws	x 3	
C	Cam Screws	x 10	
D	Cam Pins	x 10	
E	Handle & Screws	x 3	
F	T - Legs with 16 G-Screws	x 4	
G	Cover Stickers	x 2	



There we go! You are all done. Congratulations !

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.



PARIS DRAWER UNIT

Parts List

1. Left Side X1	5. Backing 3mm X3	9. Cleat X1
2. Right Side X1	6. Drawer Front X3	10. Backing 3mm X1
3. Bottom X1	7. Drawer Sides X6	
4. Top X1	8. Drawer Rear X3	



Body Assembly








- Place Top Panel (4) upside down holes facing up
- Screw Cam Pin (D) into 4 small holes.
- Insert Cam (C) into 2 large holes on Side Left (1) and Side Right (2) with arrows facing nearest side.
- Attach 6 x Drawer Runners (B) to sides (1, 2) where marked using 18 x Flat Screws supplied.
- Attach Side Left (1) and Side Right (2) to Top Panel (4) with grooves aligning with the groove on the top.
- Position Cleat (9) below Top between sides (1, 2) Guide dowels to fit into 8mm holes and tighten Confirmat Screws (A) from outside
- Insert Foil Backing (10) into back grooves of the cabinet sure to fit in groove in the top
- Secure Bottom Panel (3) to sides (1, 2) (small holes facing upwards) with 4 x Confirmat Screws (A) using the Allen Key (B)
- Attach Top Panel to sides (1, 2) with Cams (C) carefully.
- Secure T-Legs (F) to Bottom Panel(3) aligning with the small guide holes in Bottom and fasten with provided screws.



Drawer Assembly

- Place Drawer Front (6) on a soft surface. Insert Cam Pins (D) into the small holes.
- Insert Cams (C) into big holes on drawer sides using Phillips screwdriver * (not included)
- Attach the Drawer Sides (7) over the pins on the Front (6) and tighten securely.
- Insert the Drawer Foil Backing (5) into the grooves.
- Position the Drawer Rear (8) between the sides (1,2), ensuring the Foil Backing is seated in the groove. Use 2 Confirmat Screws (A) to secure the Drawer Rear (8) to the Drawer Sides (7).
- Slide the Drawer into the main body by tilting it at a downward angle, ensuring the wheels fit inside the guides on the sides of the body.
- Don't forget to attach the handles (E) after assembly.

Hardware

A	Confirmat Screws (use supplied Allen Key)	x 12	
B	3 x Sets Drawer Runners with 18 x Flat Screws	x 3	
C	Cam Screws	x 10	
D	Cam Pins	x 10	
E	Handle & Screws	x 3	
F	T - Legs with 16 G-Screws	x 4	
G	Cover Stickers	x 2	



There we go! You are all done. Congratulations !

CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.