



## SCOTTY WARDROBE 2 DOOR

### Parts List (12 parts)

1. Top	x 1	7. Top Shelf	x 1
2. Bottom	x 1	8. Door Left	x 1
3. Side Right	x 1	9. Door Right	x 1
4. Side Left	x 1	10. Backing 3mm	x 1
5. Cleats	x 1		
6. Skirting	x 5		

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver.

### Hardware

<b>A</b>	Confirmat Screws (use the supplied Allen Key)	x 22	
<b>B</b>	Allen Key	x 1	
<b>C</b>	Brown Glides (Attached to parts - no action needed)	x 4	
<b>D</b>	Oval Tubing Brackets	x 2	
<b>E</b>	Oval Tubing	x 1	
<b>F</b>	Pothole Hinges(36 Screws)	x 6	
<b>G</b>	Handles (4 Screws)	x 2	
<b>H</b>	Backing Screws	x 8	



#### CLEANING INSTRUCTIONS

**NB: Clean with a damp cloth only.**

Excessive water will cause damage, voiding the warranty.



**me&co**  
QUALITY, AFFORDABLE FURNITURE



# SCOTTY WARDROBE 2 DOOR



## Cupboard Assembly

- ▶ Place Side Right (3) on a soft surface with holes facing up. Attach the Bottom (2), Top Shelf (7) and Top (1) to Side Right by securing them with Confirmat Screws (A) and Allen Key (B) THROUGH the side - you will have to move the side to hang over the table slightly.
- ▶ Attach the Cleats (5) and Skirting (6) in the same way as the other pieces using Confirmat Screws(A). The wooden guide dowels indicate placement of each part.
- ▶ Place Side Left (4) on top of all the parts, line up with guide dowel and screw to rest of body using Confirmat Screws (A)
- ▶ Slide the Backing 3mm (10) from the Top between the Cleats and Top Shelf until locked into groove in the Bottom - make sure it is seated (check if Cover is level with the Top) and that Small holes in the Backing is nearest to top end. Use Supplied screws (H) to attached Backing to body through small holes.
- ▶ Attach Ferrari Hinges (F) to Doors (8,9) using silver screws. Flip the cupboard to upright position and screw doors to sides - see special markings (4 Mini holes for each hinge.) to Doors (8,9) using silver screws. Flip the cupboard to upright position and screw doors to sides - see special markings (4 Mini holes for each hinge). Hinges can be adjusted in 4 directions by using set screws on hinges. Screw Handles (G) to Doors.
- ▶ Fit Plastic Tubing Bracket (D) to Side Left and Divider using screws and slide Aluminum Tubing (E) in place to hang clothes.



There we go! You are all done. Congratulations !

made in sov