



URBAN BEDSIDE TABLE

Parts List




1. Ready-assembled Bedside Box with Drawer
2. Shelf



Body Assembly

- ▶ Turn Pedestal upside Down. Fit 350mm G-Legs (A) onto four corners of the bottom (pre-drilled holes) using the supplied screws and a Phillips Screwdriver. **Please note that there will be 2 x Left Facing and 2 x Right Facing Legs.**
- ▶ Align them so that the tabs on the legs all face inward.
- ▶ Fit Handle (B) using Pre-Drilled holes and supplied screws on the back of the drawer Front
- ▶ Turn the pedestal upright and place the shelf (2)with Pre-Drilled holes facing downward onto the metal tabs of the leg and fasten with supplied screws.(C)

Hardware

A	G-Legs 350 mm	x 4	
	G-Screws(9 x 16)	x 8	
B	Pull Handle	x 1	
	Screws (4 x 16)	x 2	
C	Screws (8 x 16mm)	x 8	



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.