



me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS



KELLY DESK

Parts List (8 parts)

1. Top	x 1
2. Side Left	x 1
3. Side Right	x 1
4. Shelf	x 1
5. Midblock	x 1
6. Cleat	x 1
7. 3mm Backing	x 1
8. Top Cleat	x 1

Hardware

A	Confirmat Screws <i>(use the supplied Allen Key)</i>	x 9	
B	Allen Key	x 1	
C	Cams	x 4	
D	Cam Pins	x 4	
E	Cable Outlet	x 1	
F	Legs 700mm G- Screws (9 x 16)	x 4 x 16	
G	Cover Stickers)	x 2	



Unit Assembly

- ▶ Place Top Panel (1) upside down on a soft surface. Screw 2 x Cam Pins (D) into small holes using Phillips Screwdriver.
- ▶ Push Cams (C) into big holes on the Cleat (6) with the arrow on the cam facing down.
- ▶ Place Cleat over Cam Pins and tighten.
- ▶ Flip the Top over and screw in 1 x Confirmat Screw (A) through the top Cleat.
- ▶ Flip the Top over and screw in 1 x Confirmat Screw (A) through the top into the Cleat.
- ▶ Fix Sides (2,3) and Mid Block (5) to the Top with 2 x Confirmat Screws (A) each - THROUGH the top from underneath. Leave the Screws on the Sides a little loose so the shelf can slide in.
- ▶ Screw 1 x Cam Pin (D) into the small holes on each Side (2,3)



Unit Assembly

- ▶ Slide in the Foil Backing (7) into the groove. Make sure it is properly seated in all the grooves (Sides and Top)
- ▶ Place the Shelf (4) in-between the sides (2,3) making sure the groove lines up with the Foil Backing. Put Cams (C) into the 2 x Large holes in the shelf and tighten.
- ▶ Fit Top Cleat (8) between sides and fasten with Confirmat Screws (A) through the sides.
- ▶ Turn the Desk over and fix the Legs (F) to each corner with the provides screws and pre-drilled holes. (Legs are slightly adjustable if needed)
- ▶ Fit Wire Organiser (E) into hole on Top Panel.



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.