

MOCHA PEDESTAL ASSEMBLY



Thank you for supporting us.

We believe design belongs to everyone. From materials and processes to safety testing, production and delivery, we are passionate and committed to bringing you the best possible product so you can create a beautiful space to feel comfortable in.

Here are a few assembly tips before you get started:



Make Time

The first step to all seamless assembly is taking a moment to carefully read through the instructions- you are already on your way to create a beautiful functional space!



Set The Mood

Put on your favourite playlist, order a pizza and pour yourself a drink to get in the mood!



Tool Check

Layout the instructions, screws and panels to check you have everything you need. A blanket or soft floor rug will help protect your new favourite item from scratches and a drill will speed up the assembly too!



Room Reveal

You Did it! Take a step back and enjoy the moment. Don't forget to recycle any packaging.

Creating your home

Time to assemble 30 min - People needed 1 - Difficulty level 6/10 - Tools needed - Phillips screwdriver - allen key (supplied)


MOCHA PEDESTAL ASSEMBLY



Parts List

1.	Top Panel	x 1	6.	Cabinet Backing	x 1
2.	Left Side	x 1	7.	Doors	x 2
3.	Right Side	x 1	8.	Cleat	x 1
4.	Bottom Panel	x 1	9.	Long Plinth	x 2
5.	Shelf	x 1	10.	Short Plinth	x 2

Hardware



WARNING: Any furniture that is not anchored to a wall has the potential to tip over in certain circumstances, i.e. if a child attempts to climb up on the furniture or in the event of an earthquake. Accordingly, we recommend that all furniture is anchored to a wall.




Phillips screwdrivers required. For quicker assembly, we recommend the use of a power drill on a low-speed setting.

MOCHA PEDESTAL ASSEMBLY



Step 1


Insert and tighten cam pins(**D**) into small holes in side left(**2**) and side right(**3**)
Insert cams(**C**) into big holes in shelf(**5**) ensuring arrow on cam(**C**) faces nearest edge





Step 2


Attach cleat**(8)** to the left side**(2)** and secure with a Confirmat screw**(A)** through the side**(2)**





Step 3

Attach top**(1)** to the left side**(2)** and secure with a Confirmat screw**(A)** through the side ensuring the groove in the top panel**(1)** touches the cleat**(8)**




MOCHA PEDESTAL ASSEMBLY



Step 4


Attach shelf**(5)** to the left side**(2)** and fasten cams**(C)** in shelf**(5)**





Step 5

Attach right side**(3)** to assembly and secure with Confirmat screws**(A)** and tighten cams**(C)** in the shelf**(5)**




MOCHA PEDESTAL ASSEMBLY



Step 6

Turn unit around and secure the cleat **(8)** to the top **(1)** with Confirmat screws **(A)**




MOCHA PEDESTAL ASSEMBLY



Step 7


Slide backing**(6)** into the grooves on the sides**(2,3)** ensuring it also fits into the grooves in the top panel**(1)**





Step 8

Assemble the plinth**(9,10)** assembly by inserting the dowels on the short plinths**(10)** into the holes on the long plinths**(9)**




MOCHA PEDESTAL ASSEMBLY



Step 9


Attach plinth assembly to the bottom **(4)** with Confirmat screws **(A)** through the bottom panel **(4)**





Step 10


Attach the bottom **(4)** to the cabinet assembly with Confirmat screws **(B)** through the bottom panel **(4)**





Step 11

Attach the hinges(**E**) to the cabinet doors(**7**) with supplied silver screws




MOCHA PEDESTAL ASSEMBLY



Step 12

Attach doors**(7)** to the cabinet assembly with supplied screws



MOCHA PEDESTAL ASSEMBLY



Assembled Unit

