



me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS



OSLO BOOKSHELF

Parts List (7 Parts)

- | | | | |
|---------------|----|-----------------|----|
| 1. Side Left | x1 | 4. Top Panel | x1 |
| 2. Side Right | x1 | 5. Bottom Panel | x1 |
| 3. Shelf | x3 | 6. Backing 3mm | x1 |

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 4	
B	Allen Key	x 1	
C	Square Silver Bun Feet	x 4	
D	Chipboard Screws	x 8	
E	Cam	x 8	
F	Cam Pins	X 8	



CLEANING INSTRUCTIONS

NB: Clean with a damp cloth only.

Excessive water will cause damage, voiding the warranty.





OSLO BOOKSHELF



Unit Assembly

1. Sides Setup:

- ▶ Arrange Sides (1 & 2) on a flat surface with drilling holes facing upwards.
- ▶ Screw Cam Pins (F) into the indicated holes, ensuring they are straight.
- ▶ Insert 2 Cams (E) at the top end of the sides, ensuring the small arrows on the Cams point towards the holes.

2. Shelf Installation:

- ▶ Insert 6 Cams (E) into the holes on the Shelves (3).
- ▶ Position the Shelves over the Cam Pins on the sides (1 & 2). Tighten using a screwdriver.

3. Top Panel Attachment:

- ▶ Screw Cam Pins into the Top Panel (4) and position it over the top end. Tighten the Cams.
- ▶ Ensure the groove at the back of the Top Panel aligns with the other grooves.

4. Backing Installation:

- ▶ Slide the 3mm Backing (6) into the groove, ensuring the coloured side faces the front and is fully inserted into the top groove. Secure the back panel using the small screws.

5. Bottom Panel Setup:

- ▶ Attach the Bottom Panel (5) by screwing Confirmat Screws (A) through the Bottom Panel using the supplied Allen Key (B).

6. Bun Feet Attachment:

- ▶ Attach each Bun Foot (C) using 2 chipboard screws (D) under the Bottom Panel.

