me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS

ECONO 1200 DESK

Parts List (4 parts)

1. Side Left x 1
2. Side Right x 1
3. Top Panel x 1
4. Cleat (front of unit) x 1

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 4	
B	Allen Key	x 1	
C	Cams	x 5	
D	Cam Pins	x 5	
E	Cable Outlet	x 1	
F	Glides - Attached no action needed	x 4	

Main Assembly

- Place Top Panel (3) upside down on a soft surface (blanket, etc.) Screw 5 x Cam Pins (D) into 5 small holes using a Phillips screwdriver.
- Prepare the Cleat (4) and Side Panels (1 & 2) by inserting the Cams (C) in the large holes. Make sure arrow on cam faces the nearest side.
- Fit the Cleat (4) between Side Panels (1 & 2) ensuring the dowels fit into the holes, secure it using Confirmat screws (A).
- Attach the Prepared Cleat and Side Panels on the Top panel and tighten using the Cam Pins (D)
- Fit cable outlet (E) onto the Top Panel (3)

CLEANING INSTRUCTIONS
NB: Clean with a damp cloth only.
Excessive water will cause damage, voiding the warranty.

me&co
QUALITY, AFFORDABLE FURNITURE

ASSEMBLY INSTRUCTIONS

ECONO 1200 DESK

Parts List (4 parts)

1. Side Left x 1
2. Side Right x 1
3. Top Panel x 1
4. Cleat (front of unit) x 1

Make sure you have all the parts listed and organize them by type and size. You will also need a Phillips or star screwdriver

Hardware

A	Confirmat Screws (use the supplied Allen Key)	x 4	
B	Allen Key	x 1	
C	Cams	x 5	
D	Cam Pins	x 5	
E	Cable Outlet	x 1	
F	Glides - Attached no action needed	x 4	

Main Assembly

- Place Top Panel (3) upside down on a soft surface (blanket, etc.) Screw 5 x Cam Pins (D) into 5 small holes using a Phillips screwdriver.
- Prepare the Cleat (4) and Side Panels (1 & 2) by inserting the Cams (C) in the large holes. Make sure arrow on cam faces the nearest side.
- Fit the Cleat (4) between Side Panels (1 & 2) ensuring the dowels fit into the holes, secure it using Confirmat screws (A).
- Attach the Prepared Cleat and Side Panels on the Top panel and tighten using the Cam Pins (D)
- Fit cable outlet (E) onto the Top Panel (3)

CLEANING INSTRUCTIONS
NB: Clean with a damp cloth only.
Excessive water will cause damage, voiding the warranty.